

Author: Tony Ranger
Technical Director
Theorem Solutions Limited

Presenter: Tom Kloecker

tony@theorem.co.uk tom@theorem-usa.com



STEP may be used to define data for the whole product for the complete life cycle

Here we are talking within the context of model geometry

data exchange



Why do we need healing for STEP

Healing is often taken as the means of fixing bad data

Healing here is also defined to be the means of manipulating data to make it fit for a purpose other than that for which it was created



.... a means of manipulating data to make it fit for a purpose other than that for which it was created -

transfer between systems

different tolerances

different validity rules

transfer between disciplines

for example - removal of fillets / blends




Healing can also be applied to the need to manipulate data which is not as intended

Not what the user expected or wanted

Not what the originating system intended



Theorem Product Architecture





CADhealer provides processing of


System A to STEP

STEP to system B

STEP to STEP



CADhealer - Analyse and Fix Options





CADhealer - Analyse and Fix Options

Allows user to examine and process ...

Small features

Accuracy issues

Topology issues


Orientation errors

Shell issues


Surface sewing problems

Blend removal or replacement


































































































































































X CADhealer Opti	on Dialogue]
Topology	Sewing Mode ♦ Sew ♦ Unsew	
Sewing		ı
Trimming	■ Evaluate ■ Unsew Single Face	ı
Solids	Sew All Tolerance D.001	ı
Features	■ Sew Selected	ı
Faces/Edges		ı
Curves		ı
Highlight		ı
Fine Tune	Apply Report Help Cancel	
	Apply Report Reip Calicer	




Small Edge Problems






Removal of Small Edge






Sliver Face Problems






Removal of Sliver Face






Face Spike Problems







Removal of Face Spike













Solid Gap Healing

Basic Assumptions

The body - topology and geometry - provides a definition of the design intent which is accurate to a certain modelling tolerance

It is permissible to manipulate the topology and geometry by amounts which are small relative to engineering and manufacturing tolerances in order to provide a new definition of the body



Solid Gap Healing

Body

Face

Edge

Vertex

Surface Curve

Point

Surface

Intersection

Curve

Intersection

Multiple Surface

Intersection



Solid Gap Healing

Surfaces Rule

=> Edges and vertices redefined from surfaces



Solid Gap Healing

Edges classified as intersecting or parallel

Intersecting edges recalculated if necessary

Parallel edges => surface modification



Summary

STEP is becoming an accepted and successful option for moving data between systems.

As different systems have different validity and tolerance requirements some manipulation of the data is necessary.

Interactive access to 'Healing' software provides options to improve successful data exchange. (As confidence grows, automatic healing may become acceptable.)